

How to install the software?


- a) Run "DataUpload\_Setup.exe"
- b) The step of installation is running automatically
- c) You will get a "shortcut" named "DataUpload" in your "Program File"
- d) Run this "shortcut" named "DataUpload", the software will be OK.

How to transfer the stored data to PC?

Instructions on transferring data (Version 3.2.5)


When opening the software firstly, please do not connect the communication cable between the main unit and PC.

1. Display like this



When connecting the main unit to PC, it displays automatically in some seconds like this. At this time, there is a port that is active by your PC.

Here our model is COM4.




2. When operating the main unit and transferring data, the steps is as follows:


2.1 Press menu key to Print function, like this:



2.2 Press menu key and enter





2.3 Choose the data you want to transfer, like this:




2.4 Press confirm key again to begin data transfer.

2.5 After data transfer, it is like this:







3. If you want to store the data in different format, such as “\*.xls”, “\*.doc”, “\*.rtf” and “\*.txt”. Please follow the steps below.



3.1 Choose different format you want:



3.2 After setting, you will find a file with the name you set, like this:



Open it, like this:

@U DHT-100

UOPER:

MAT: 1

DIR: 1

IMPACT:D

2012.06.18 13:52

LOCATION: 0000

NO.	HL
1	779
2	782
3	780
AVG	780

LOCATION: 0001

NO.	HL
1	777
2	780
3	778
AVG	778

LOCATION: 0002

NO.	HL
1	780
2	779
3	780
AVG	780

END OF PRINT

Notice: some unjustifiable symbol will display in the step of transmission,  
you should delete them before you save the data.